

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Калининград (4012)72-03-81	Омск (3812)21-46-40	Сыктывкар (8212)25-95-17
Ангарск (3955)60-70-56	Калуга (4842)92-23-67	Орел (4862)44-53-42	Тамбов (4752)50-40-97
Архангельск (8182)63-90-72	Кемерово (3842)65-04-62	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Киров (8332)68-02-04	Пенза (8412)22-31-16	Тольятти (8482)63-91-07
Барнаул (3852)73-04-60	Коломна (4966)23-41-49	Пермь (342)205-81-47	Томск (3822)98-41-53
Белгород (4722)40-23-64	Кострома (4942)77-07-48	Петрозаводск (8142)55-98-37	Тула (4872)33-79-87
Благовещенск (4162)22-76-07	Краснодар (861)203-40-90	Псков (8112)59-10-37	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Красноярск (391)204-63-61	Ростов-на-Дону (863)308-18-15	Улан-Удэ (3012)59-97-51
Владивосток (423)249-28-31	Курган (3522)50-90-47	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Владикавказ (8672)28-90-48	Курск (4712)77-13-04	Самара (846)206-03-16	Уфа (347)229-48-12
Владимир (4922)49-43-18	Липецк (4742)52-20-81	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Волгоград (844)278-03-48	Магнитогорск (3519)55-03-13	Саранск (8342)22-96-24	Чебоксары (8352)28-53-07
Вологда (8172)26-41-59	Москва (495)268-04-70	Саратов (845)249-38-78	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Мурманск (8152)59-64-93	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Набережные Челны (8552)20-53-41	Симферополь (3652)67-13-56	Чита (3022)38-34-83
Иваново (4932)77-34-06	Нижний Новгород (831)429-08-12	Смоленск (4812)29-41-54	Якутск (4112)23-90-97
Ижевск (3412)26-03-58	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31	Ярославль (4852)69-52-93
Иркутск (395)279-98-46	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13	
Казань (843)206-01-48	Ноябрьск (3496)41-32-12	Сургут (3462)77-98-35	

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

yna@nt-rt.ru || <https://yanan.nt-rt.ru>

Аксессуары и комплектующие для стандартных и опциональных конфигураций Техническое описание

STANDARD AND OPTIONAL CONFIGURATIONS

● = Standard, □ = Optional

MECHANICAL STRUCTURE	
All weather and sound proof canopy (for soundproof type)	●
Corrosion resistant coating	●
Forklift holes on base frame or other removable lifting device	□
Built-in bottom fuel tank with fuel level sensor	●

CONTROL SYSTEM AND ELECTRICAL FACILITIES	
DEEP SEA DSE6120 AMF function control module	●
Synchronising and load share control module	□
Remote control or communication function	□
Standard 3P output circuit breaker	●
4P output circuit breaker or high protection grade switches socket kit	□
Integrated ATS	□
Starting Battery(ies) with connecting cables and mounting frame	●
Battery trickle type charger	●
Maintenance free batteries	□

DIESEL ENGINE	
4- strokes , water cooled ,direct injection diesel engine	●
starting motor and charging alternator	●
Standard dry type air filter with replaceable element	●
Air intake pre-filter for heavy duty and dusty environment application	□
Oil drain extension & shut off valve	●

AC ALTERNATOR	
Class H, single bearing brushless, standard AVR and excitation system	●
Self-ventilated cooling system	●
4 poles, rotating field	●
Bearing and winding temperature detector (RTD)	□
Marine winding for salt-spray environment application	□
Anticondensation	□

FUEL SYSTEM	
Built-in fuel tank for 6-10 hours endurance	•
Fuel level sensor	•
Built-in fuel tank for 24 hours endurance	☐
Free standing daily fuel tank	☐
Leak-proof double wall fuel tank	☐
Water / fuel separator	☐
Automatic refueling device	☐

LUBRICATING SYSTEM	
Used oil drain plug and shut off valve	•
Oil pressure monitoring and protection	•
Replacement, full flow, cartridge type oil filter	•
Oil level maintainer and new oil reservoir for long time endurance	☐
Oil pre-heater	☐

COOLING SYSTEM	
Vertical type radiator for 40°C environment temperature	•
Fan and moving parts protective shield	•
Coolant pre-heater	☐
Horizontal type or other remote type radiator	☐
Marine grade radiator for salt-spray environment application	☐
50°C environment temperature radiator	☐
Stainless steel plate heat exchanger with water circulating pump	☐

EXHAUST SYSTEM	
Industrial muffler	•
Secondary muffler	☐
Heat protection shield outside the exhaust manifold	•
Heat insulation clamp outside the exhaust pipe	•
Rainproof cover at exhaust pipe tail end	☐
Stainless steel flexible joint, elbow joint	•
Catalytic particulate filter and catalytic purifier	☐

OTHERS	
Maintenance and operation manual	•
Electrical diagram	•
Tool kit	•

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Калининград (4012)72-03-81	Омск (3812)21-46-40	Сыктывкар (8212)25-95-17
Ангарск (3955)60-70-56	Калуга (4842)92-23-67	Орел (4862)44-53-42	Тамбов (4752)50-40-97
Архангельск (8182)63-90-72	Кемерово (3842)65-04-62	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Киров (8332)68-02-04	Пенза (8412)22-31-16	Тольятти (8482)63-91-07
Барнаул (3852)73-04-60	Коломна (4966)23-41-49	Пермь (342)205-81-47	Томск (3822)98-41-53
Белгород (4722)40-23-64	Кострома (4942)77-07-48	Петрозаводск (8142)55-98-37	Тула (4872)33-79-87
Благовещенск (4162)22-76-07	Краснодар (861)203-40-90	Псков (8112)59-10-37	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Красноярск (391)204-63-61	Ростов-на-Дону (863)308-18-15	Улан-Удэ (3012)59-97-51
Владивосток (423)249-28-31	Курган (3522)50-90-47	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Владикавказ (8672)28-90-48	Курск (4712)77-13-04	Самара (846)206-03-16	Уфа (347)229-48-12
Владимир (4922)49-43-18	Липецк (4742)52-20-81	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Волгоград (844)278-03-48	Магнитогорск (3519)55-03-13	Саранск (8342)22-96-24	Чебоксары (8352)28-53-07
Вологда (8172)26-41-59	Москва (495)268-04-70	Саратов (845)249-38-78	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Мурманск (8152)59-64-93	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Набережные Челны (8552)20-53-41	Симферополь (3652)67-13-56	Чита (3022)38-34-83
Иваново (4932)77-34-06	Нижний Новгород (831)429-08-12	Смоленск (4812)29-41-54	Якутск (4112)23-90-97
Ижевск (3412)26-03-58	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31	Ярославль (4852)69-52-93
Иркутск (395)279-98-46	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13	
Казань (843)206-01-48	Ноябрьск (3496)41-32-12	Сургут (3462)77-98-35	

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

yna@nt-rt.ru || <https://yanan.nt-rt.ru>